



الحرس الوطني

إرشادات
جهاز الأمن والسلامة البحري

**Security and Safety Device (E-PASSPORT)
Instructions**



The Maritime Security & Safety Device

Definition of the Maritime Security and Safety Device:

The Maritime Security and Safety device is an electronic device approved by the Ministry of Defence and installed on a marine craft. The device helps in responding to distress signals by pressing the emergency button attached to it. The device is considered one of the most important modern tools for ensuring quick response and assistance in marine locations.

Installation method:

1. The device is connected to the main switch of the Maritime craft.
2. The device will automatically activate when the engine main switch is started.
3. The device is installed inside the cockpit (in a safe place).

Antenna:

The antenna is installed above the cockpit or above the canopy of the marine craft in an open place.

Instruction Panel:

The device's instructions panel is installed on the cockpit in a visible place, allowing the captain to see it clearly to receive any instructions for exceeding the speed, avoiding being in unauthorized place, ensuring that the device is working, and access the emergency button in case of any emergency situation.

Procedures to be followed by the marine craft owner in the event that alerts appear on the instruction panel:

1. Contact CICPA :

The marine craft owner or his representative shall visit the nearest Coast Guard checkpoint.

2. Over Speed :

Reduce speed whenever an over speed alert appears, especially in internal areas.

3. Zone Violation :

You must leave the prohibited zone immediately.

4. Emergency button :

When you need to use the **emergency button**, press the button until it lights up and try to communicate on No.: (996) and wait for a response from the Coast Guard.


The Maritime Security & Safety Device

Instructions for maintaining maritime security and safety device

1. The owner or his representative must maintain the security and safety devices, as the device is a private property of the Ministry of Defence. He shall follow the instructions :
 - Avoid pumping water onto the device, directly or indirectly.
 - Avoid pumping water onto the instruction panel, directly or indirectly.
 - Avoid manipulating the device or its accessories.
2. If the owner or his representative wishes to perform boat maintenance that may potentially damage the device or its accessories, they must consult the Coast Guards or the Maritime Licensing Section for proper dismantling procedures. Ensure that the device is functioning properly and has no issues before using the marine craft (prior sailing).
3. **ALERT** : In case that the device is exposed to any damage, loss, or malfunction out of your control, report it to the nearest Department of Cost Guard within **24 hours** or contact phone number **996**.

معلومات لوحة الإنذار

INSTRUCTION PANEL INFORMATION



الأردية URDU	الانجليزية ENGLISH	العربية ARABIC
كام کرتا ہے۔	Power	الجهاز يعمل
سرخ رنگ - بطری کم نارنجی رنگ - بطری چارجنگ سبز رنگ - بطری چارج شدہ	RED COLOR - LOW BATTERY ORANGE COLOR - BATTERY CHARGING GREEN COLOR - BATTERY CHARGED	اللون احمر البطارية غير مشحونة اللون برتقالي، جاري شحن البطارية اللون اخضر، البطارية مشحونة
● ● ●	● ● ●	● ● ●



National Guard

رقم الطوارئ

Emergency Number

996



ATLAS
— TELECOM —